



**Datum** 11.9.2018 / 12.9.

**Papier**  Adox Fine Print Variotone (Baryt)  Fomabrom Variant 111 (Baryt)  Kodak Premier Endura (F)  \_\_\_\_\_

**Vergrößerer**  Durst Laborator 1200/CLS 500  Durst M670 Color  Ilford DT600  Kaiser 4030 Fernobox 66N

**Objektiv**  Componon-S 2.8/50  EL-Nikkor 5.6/80  Componon-S 5.6/150  \_\_\_\_\_

**Chemie**  Moersch ECO 4812 1+14  Tetenal Eukobrom 1+9  Adox RA-4 (Maschine ACP 302)  \_\_\_\_\_

Moersch ATS alk. 1+5  Moersch MT1 Se-Toner 1+10  Adox Adostab 1+20  \_\_\_\_\_

neuer Ansatz  Entwickler  Stopbad  Fixierer 2  HCA Stamm  Adostab  Selen  RA-4  \_\_\_\_\_

Baryt: 3 min Entwickler | 30s Stop | 1,5min Fix 1 (max 3g Ag<sup>+</sup>/l) | 1,5min Fix 2 | Wasser | Selen  60sek.  3 min | Wasser | 3 min HCA | Schlusswässerung | 2 min Adostab

Color: ACP 302 | abspülen: 1 min | wässern: 1 min – 2 min – 3 min (je frisches Wasser, 9 je > 32°C) | ~~abrufen~~ | trocknen

Print Nr.	Motiv	Negativ-Nr.	Papier-format	f/	Abstand Film – Papier	Filterung		-Zeit	Ap	fP	Se
						Y	M				
1113	Prora 7.6.17	<input type="checkbox"/> KB	30/40	11	21	88	90	12s		X	
1114		<input checked="" type="checkbox"/> MF 4,5+6									
1115	Prora 160 <input type="checkbox"/> Maske	<input type="checkbox"/> GF #42									
1116	Prora dto.	<input type="checkbox"/> KB	"	"		88	90		X	(gering)	
1117		<input type="checkbox"/> MF									
1118	<input type="checkbox"/> Maske	<input type="checkbox"/> GF									
1119		<input type="checkbox"/> KB	2							X	
		<input checked="" type="checkbox"/> MF									
1120	Prora Kaimauer „Alte“ <input type="checkbox"/> Maske	<input type="checkbox"/> GF									
1121	"	<input type="checkbox"/> KB	30/40	11		85	90	11s		X	
1122		<input checked="" type="checkbox"/> MF									
1123	<input type="checkbox"/> Maske	<input type="checkbox"/> GF									
1124	Prora Kaimauer / Meer	<input type="checkbox"/> KB	30/40	11	90,5	88	88	15s	X	X	
1125	" 1/3	<input checked="" type="checkbox"/> MF									
1126	" 2/3 <input type="checkbox"/> Maske	<input type="checkbox"/> GF									
1127	" 3/3	<input type="checkbox"/> KB	46							X	
1128	Prora Teppe 1 1/3 <input type="checkbox"/> Maske	<input checked="" type="checkbox"/> MF									
		<input type="checkbox"/> GF									
1129		<input type="checkbox"/> KB	#5							X	
1130		<input checked="" type="checkbox"/> MF									
		<input type="checkbox"/> GF									

12.9.



**Datum** 4.5.19 / 5.5.19  
**Papier**  Adox Fine Print Variotone (Baryt)  Fomabrom Variant 111 (Baryt)  Kodak Premier Endura (F)  \_\_\_\_\_  
**Vergrößerer**  Durst M670 Color  Durst Laborator 1200/CLS 500 Femobox 66N  Kaiser 4030  
**Objektiv**  Componon-S 2.8/50  EL-Nikkor 5.6/80  Componon-S 5.6/150  Focotar-2 4.5/50 (426 1167)  
**Chemie**  Moersch ECO 4812 1+14  Tetenal Eukobrom 1+9  Adox RA-4 (Maschine ACP 302)  \_\_\_\_\_  
 Moersch ATS alk. 1+5  Moersch MT1 Se-Toner 1+10  Adox Adostab 1+20  \_\_\_\_\_  
 neuer Ansatz  Entwickler  Stopbad  Fixierer 2  HCA Stamm  Adostab  Selen  RA-4  \_\_\_\_\_

Baryt: 3 min Entwickler | 30s Stop | 1,5 min Fix 1 (max 3g Ag<sup>+</sup>/l) | 1,5 min Fix 2 | Wasser | Selen  60 sek.  3 min | Wasser | 3 min HCA | Schlusswässerung | 2 min Adostab  
 X Color: ACP 302 | abspülen: 1 min | wässern: 1 min – 2 min – 3 min (je frisches Wasser, 9 je > 32°C) | trocknen  IR  Luft

Print Nr.	Motiv	Negativ-Nr.	Papier-format	f/	Abstand Film – Papier	Filterung		Zeit	Ap	fP	Se
						Y	M				
1152 1153 1154	Kaimanes Prora 113 } 213 } 4er Tablea 5/19 313 } <input type="checkbox"/> Maske	<input type="checkbox"/> KB	30/40	16	71,5	86	87	12s		X	
		<input checked="" type="checkbox"/> MF 2,5									
		<input type="checkbox"/> GF									
1155 1156 1157	Heer durch Zaun 113 } 213 } 4er-Tablea 5/19 313 } <input type="checkbox"/> Maske	<input type="checkbox"/> KB	"	"	"	"	"	"		X	
		<input checked="" type="checkbox"/> MF 4									
		<input type="checkbox"/> GF									
1158 1159 1160	Jonathan 7/17 Bobi - Porke 160 <input type="checkbox"/> Maske	<input type="checkbox"/> KB	"	16	"	85	100	12s		X	
		<input checked="" type="checkbox"/> MF 46									
		<input type="checkbox"/> GF									
1161 1162 1163 1164	Theodor/Arzt 2/19 Ultramax <input type="checkbox"/> Maske	<input checked="" type="checkbox"/> KB	3/40	8	84cm	95	103	18s		X	
		<input type="checkbox"/> MF 22									
		<input type="checkbox"/> GF									
1165 1166 1167 1168	Theodor Baumwipfelpfad 29.12.18 Porke 800 <input type="checkbox"/> Maske	<input type="checkbox"/> KB	"	16	71,5	60	100	10s		X	
		<input checked="" type="checkbox"/> MF 4,5									
		<input type="checkbox"/> GF									
	<input type="checkbox"/> Maske	<input type="checkbox"/> KB									
		<input type="checkbox"/> MF									
		<input type="checkbox"/> GF									
	<input type="checkbox"/> Maske	<input type="checkbox"/> KB									
		<input type="checkbox"/> MF									
		<input type="checkbox"/> GF									